



## Motor Amperage Requirements by Horse Power

Motor HP	200 VAC	208 VAC	230 VAC	380 VAC	400 VAC	415 VAC	460 VAC	480 VAC	575 VAC
15	—	41 <b>60</b>	36 <b>63</b>	—	21 <b>16-27</b>	21 <b>18-25</b>	18 <b>18-25</b>	—	17 <b>16-27</b>
30	—	86 <b>125</b>	76 <b>100</b>	—	42 <b>80</b>	43 <b>80</b>	38 <b>50</b>	—	32 <b>50</b>
50	132 <b>175</b>	128 <b>175</b>	122 <b>175</b>	69 <b>100</b>	66 <b>100</b>	64 <b>100</b>	58 <b>100</b>	—	52 <b>80</b>
60	—	—	142 <b>175</b>	83 <b>125</b>	—	—	71 <b>100</b>	—	—
75	198 <b>250</b>	—	172 <b>250</b>	—	98 <b>175</b>	—	86 <b>175</b>	—	86 <b>100</b>
100	—	—	248 <b>300</b>	—	124 <b>175</b>	120 <b>175</b>	—	105 <b>175</b>	99 <b>125</b>

Full Load Amps  
Circuit Breaker Amps

Please Print This Page For Reference

# SOUTHERN FABRICATING

MACHINERY SALES

## About SFMS



With an extensive working knowledge of manufacturing systems, going back over 30 years coupled with real hands-on shop experience, our representatives can best assist you in locating and securing the best machinery for your application. Along with our own inventory, we can choose solutions from a close network of partners. If we don't have the solution you're looking for, we will find it.

[southernfabsales.com](http://southernfabsales.com)

PO Box 1789

Riverview FL, 33569

P: 813.444.4555

F: 813.333.0450

